



### Minor assembly required.

#### Tools recommended

Crescent wrench  
 Phillips screwdriver  
 Plumbers tape  
 Slip joint pliers



**\*\*THIS PRODUCT IS NOT INTENDED FOR USE WITH BABY CHICKS\*\***

### Preparing pan, float and hose for use

The metal float cover may be removed to help with the assembly process. (Remove screws and lift them and metal cover out.)

1. Screw supplied small female adapter end onto float assembly and tighten. Make sure hose washer is in other end  
**\*Recommendation:** Add plumbers tape on male end of float assembly before attaching adapter.
2. Screw male end of supplied hose into other end of adapter and tighten  
 Only attach supplied hose to adapter. Other garden hoses may leak inside adapter due to different fittings  
**\*Recommendation:** Add plumbers tape on male end of hose before attaching to adapter
3. Attach female end of hose to water supply and turn water on. Wait approximately 15 minutes for float to shut water off to pan.

The water level is preset at the factory; however, minor adjustments can be made to increase or decrease the water level in the waterer if desired.

To adjust the water level, remove the metal float cover, then remove float arm assembly by pulling out the connecting pin, loosen the float mounting screw and nut with a screwdriver, then rotate the float arm up or down to achieve desired water level. Make sure you retighten the mounting screw and nut securely.

**CAUTION:** Rotating the arm too far up or failing to secure the float mounting screw and nut may prevent the waterer from stopping the water supply flow and run continuously.

**\*\*\*Do NOT use this product in freezing temperatures\*\*\***

#### Operating Tips:

If the water flow does not stop:

1. Make sure water supply pressure is below 50 psi
2. Make sure float arm moves up and down freely without binding
3. Make sure float is not hitting the metal float cover when closed
4. Remove float pin and float arm assembly:
  - a. Check for water inside the float. Replace SW23 float if necessary.
  - b. Remove any debris from valve tip or valve seal and test
  - c. Replace SW8 seal and test. (An additional seal is provided on the side of the float arm)
  - d. Check SW20 valve tip for chips, surface imperfections, or cracks. Replace valve if necessary.

### Preparing Anti-Roosting Cover for use (No tools required)

1. Remove the mounting stem with magnet and adjusting hardware from the plastic bag.
2. Remove the wing nut and one flat washer from top of stem assembly. Height of plastic cover is adjustable by moving supporting nut and washers up or down the stem to desired height.
3. Place plastic cover on stem and replace flat washer and wing nut.
4. Tighten all hardware to secure assembly position of cover on stem.
5. Apply magnet to center of metal float cover.



Height of Anti-Roosting cover on stem can easily be changed  
 Entire magnet assembly of cover can be removed if or when needed.